


Install manual

IS-SL2-485




Install




Terminal Information

Terminal Type	
min Capacity	0.5 mm ²
max Capacity	2.5 mm ²
Torque	0.6 Nm
Strip Length	

Alarm Information



Dimension Information



Mounting

